

CAM-FD5-AD

Reverse Camera Add On Interface For select Ford vehicles

APPLICATION:

Ford B-Max (B232)	2012 >	Ford C-Max (C344)	2010-2019
Ford Ecosport (2nd Gen) 2013 >	Ford Fiesta (MK7 Facelift)	2012-2018
Ford Focus (MK3/C346)	2011-2018	Ford Ka (MK3)	2016 >
Ford Kuga (C520)	2013-2019	Ford Mondeo (MK5)	2014 >
Ford Ranger (3rd Gen)	2011 >	Ford S-Max (2nd Gen)	2015 >
Ford Transit Connect (MK2) 2014-2019	Ford Transit Courier	2014 >
Ford Transit Custom (M	K1) 2013-2018	Ford Transit (MK8)	2013-2018

Allows for the addition of an aftermarket reverse camera to the original vehicle screen. This harness works with models which feature factory SYNC1 systems with 4.5" colour screens, without navigation (will not work with non-colour/monochrome screens).

Note: the camera being paired with this product must be NTSC. Vehicle coding of the camera input is needed, visit a Ford dealership to get coded.

DISCLAIMER:

Prior to Installation

Read the manual prior to installation. Technical knowledge is necessary for installation. The place of installation must be free of moisture and away from heat sources. Please ensure you use the correct tools to avoid damage to the vehicle or product.

Connects2 can not be held responsible for the installation of this product.

Technical Support

Connects2 want to provide a fast and suitable resolution should you encounter any technical issues. With this in mind, when contacting Connects2, try to provide as much Information as possible. This will speed up the process and help us to help you. Please use our dedicated online technical support centre: support.connects2.com

CONTENTS

- Reverse Camera Add On Adapter
- Instructions

INSTALLATION

- 1. Remove the vehicles head unit & display by following the manufacturer's instructions/guidelines. Once removed, disconnect all the power connections including the 12-pin connector on the back of the display.
- 2. With the aftermarket camera installed, connect the cameras RCA to the yellow RCA of the CAM-FD5-AD.
- 3. Attach the 12-pin specific connector to the back of the display. When done, connect the vehicles power to the opposite side of the CAM-FD5-AD and test the reverse camera's functionality before reassembling the dashboard.

Please note: coding of the vehicle must take place well before installation in order for the camera to work correctly.



Subscribe to our YouTube Channel for installation guides and tips... www.youtube.com/connects2