



## User Manual

# CAM-VW2-RT

OEM Reverse Camera Retention Interface  
For Volkswagen and Skoda Vehicles

---

### APPLICATION:

#### Volkswagen

Passat	2010 - 2015
Golf	2008 - 2014
Touran	2010 - 2015
Transporter	2009 - 2014
Polo	2008 - 2014
Jetta	2009 - 2014
EOS	2009 - 2014
Amarok	2010 - 2014
Scirocco	2008 - 2015
Tiguan	2009 - 2015

#### Skoda

Octavia	2009>
Superb	2008 - 2015

---

### DISCLAIMER:

#### Prior to Installation

Read the manual prior to installation. Technical knowledge is necessary for installation. The place of installation must be free of moisture and away from heat sources. Please ensure you use the correct tools to avoid damage to the vehicle or product.

***Connects2 can not be held responsible for the installation of this product.***

#### Technical Support

Connects2 want to provide a fast and suitable resolution should you encounter any technical issues. With this in mind, when contacting Connects2, try to provide as much Information as possible. This will speed up the process and help us to help you.

**Please use our dedicated online technical support centre: [support.connects2.com](http://support.connects2.com)**

- OEM Camera Retention Interface
- Instructions

## INSTALLATION

---

1. Connect the yellow RCA connector from the interface to the camera input on the rear of the aftermarket head unit
2. Connect the vehicle specific connector from the interface to the vehicle harness
3. Connect the black flying wire to Ground
4. Connect the blue flying wire to Reversing light power
5. Connect the yellow wire to ACC+ (Battery permanent)



Subscribe to our YouTube Channel for installation guides and tips... [www.youtube.com/connects2](http://www.youtube.com/connects2)