

CTSMZ003.2 Mazda Steering Wheel Control Interface





















Vehicle Application

Mazda 6 2007 - 2009

For Non Amplified Vehicles

Key Features

- Retains Steering Wheel Controls (if equipped)
 - Allows Clock Adjustment via SWC
 - Allows Trip Computer Access via SWC
- Provides Park Brake, Speed Pulse, Reverse Gear, Amp Remote, Illumination Feeds





ABOUT THIS PRODUCT

CTSMZ003.2

CAN-Bus Steering Wheel Control Interface for select non amplified Mazda vehicles

WIRING COLOUR CODES

Yellow Permanent 12V **Purple** Right Rear Speaker + Purple/Black Right Rear Speaker -Black Ground Green Left Rear Speaker + Red Ianition 12V Green/Black Left Rear Speaker -Orange Illumination Grev Right Front Speaker + Blue/White Amp Remote Grey/Black Pink Speed Pulse Right Front Speaker -White Left Front Speaker + Green Park Brake White/Black Left Front Speaker -Purple/White Reverse Gear

PRIOR TO INSTALLATION

Read the manual prior to installation. Technical knowledge is necessary for installation. The place of installation must be free of moisture and away from heat sources. Please ensure that the correct tools are using during the installation to avoid damage to the vehicle or product. **Connects2 can not be held responsible for the installation of this product.**

TECHNICAL SUPPORT

Connects2 Ltd. want to provide a fast and suitable resolution to any problems encountered during installation of this product. To get in touch with our dedicated technical support team, please fill in a ticket at **support.connects2.com** and provide as much information as possible.

FOLLOW US ON SOCIAL MEDIA for all the latest updates



/CONNECTS2
Watch us on YouTube



Like us on facebook



CONNECTS2LTD
Follow us on instagram







FITTING GUIDE

- 1. Remove and disconnect the original head unit.
- 2. Connect the 12 way molex connector of the head unit patch lead (supplied separately) to the interface.





3. Connect the opposite end of head unit patch lead to the head unit steering wheel control input on the back of the aftermarket head unit.

NB: This may be a 3.5mm jack plug or a wire input depending upon the head unit brand being fitted. Please see the head unit installation manual for further information on where to connect.

Important: This step must be completed before connecting power to the interface. Failure to so do may result in no steering wheel control function.



4. Connect the 14 way molex connector to the interface





5. Connect the male power/speaker ISO harness to the female power/speaker ISO harness from the aftermarket head unit. For aftermarket head units without an ISO connector, please refer to "Wiring Colour Codes" on Pa. 2.





FITTING GUIDE

6. Connect the female vehicle specific connectors on the harness to the male vehicle connector from the vehicle. Test head unit for correct operation.

STEERING WHEEL CONTROL FUNCTIONALITY

Original Button	Function
Up Arrow	Volume +
Down Arrow	Volume -
Right Arrow	Track +
Left Arrow	Track -

Adjusting the Clock

- 1. Press and hold 'SET' button for 2 seconds
- 2. Press 'Up' to change the hours and 'Down' to change the minutes
- 3. Press and hold 'SET' button to exit the menu or wait 10 seconds for the menu to time out automatically

To Navigate Trip Computer

- 1, Press the Right Arrow repeatedly until the clock in the vehicle display is highlighted
- 2. Press the 'Up' and 'Down' keys to navigate the trip computer

To Reset Trip Computer

- 1. Navigate to the trip computer setting you wish to reset (as shown above)
- 2. Press and hold 'SET' until the reading clears. The display should show '