



...connecting to the aftermarket

Connects2Vision

User Manual

RVM7

7" TFT Colour Monitor

PRODUCT FEATURES:

- 7" TFT Colour Monitor
- Brightness/Contrast/Colour Adjustment
- Language Adjustment
- 16:9/4:3 Viewing Option
- 4 Position Screen Setting
- PAL/NTSC
- 100:1 Contrast Ratio
- Pixels: 480 (W) RGB 234 (H)
- Bracket Stand or Flush Mounting Options
- Infra-Red Remote Control
- Operating Current = 320mA @ 13.8V
- Standby Current = 56mA @ 13.8V
- Power Consumption = 4.5W

DISCLAIMER:

Prior to Installation

Read the manual prior to installation. Technical knowledge is necessary for installation. Please ensure you use the correct tools to avoid damage to the vehicle or product.

Connects2 can not be held responsible for the installation of this product.

Technical Support

Connects2 want to provide a fast and suitable resolution should you encounter any technical issues. With this in mind, when contacting Connects2, try to provide as much information as possible. This will speed up the process and help us to help you.

Please use our dedicated online technical support centre: support.connects2.com

CONTENTS

- 7" TFT Colour Monitor
- Infra-Red Remote Control
- Adjustable Dash Mount Bracket & Flush Mount Holder
- 2x Video Input Cable w/ Auto-Switching Functionality

INSTALLATION

1. Connect the main harness to the monitor.
2. Connect the AV1 input (designated by default as the front camera input) to the front-facing camera
3. Connect the AV2 input (designated by default as the reverse camera input) to the reverse camera on the vehicle.
4. Connect the green reverse trigger wire on the main harness to the reverse circuit on the vehicle or an interface which provides a reverse signal. This will allow the monitor to switch the image automatically to AV2 when reverse gear is engaged.



Subscribe to our YouTube Channel for installation guides and tips... www.youtube.com/connects2