

## **APPLICATIONS**

**Toyota Matrix 2009**

**Pontiac Vibe 2009**

**(Excluding Factory Navigation Models)**

# CT23TY16



### **KIT FEATURES**

- Double DIN Radio Provision
- Stacked ISO Mount Units Provision



### **KIT COMPONENTS**

- A) Double Din Trim Plate
- B) Double DIN Brackets



### **TOOLS REQUIRED:**

- Small Flat Blade Screwdriver/ Panel Removal Tool
- Socket Set



# **TABLE OF CONTENTS**

## **Dash Disassembly**

**- Toyota Matrix/Pontiac Vibe 2009 ..... 1**

**Kit Preparation ..... 2**

## **Kit Assembly**

**- Double DIN Radio Provision . . . . . 3**

**- Stacked ISO Mount Units Provision . . . . . 3**

**Final Assembly ..... 4**



### **\*Note:**

**Refer also to the instructions included with the aftermarket radio.**

# Toyota Matrix/Pontiac Vibe 2009

- 1 Disconnect the negative battery terminal to prevent an accidental short circuit.
- 2 Unclip and remove the radio trim panel including the a/c vent. (Figure A)
- 3 Remove (4) 10 MM bolts securing the radio. Unplug and remove the radio. (Figure B)

*Continue to kit preparation.*




## DOUBLE DIN RADIO PROVISION STACKED ISO MOUNT UNITS

*\*Note: Refer also to the instructions included with the aftermarket radio.*

- 1 Snap the Double DIN Trim plate into the rear of the factory radio trim panel. (Figure A)

*Continue to kit assembly.*



## **DOUBLE DIN RADIO PROVISION STACKED ISO MOUNT UNITS PROVISION**

*\*Note: Refer also to the instructions included with the aftermarket radio.*

- 1** Attach the Double DIN brackets to the Double DIN or the stacked ISO mount unit(s) using the screws supplied with the unit(s). (Figure A)

*Continue to final assembly.*

