



CT51-MC07

Amplifier Retention Adapter for Mercedes Benz/Porsche Vehicles



IN THE KIT

- Universal Wiring Harness
- Fibre Optic Retention Interface

APPLICATION

Note: Application data is subject to change at any time

Mercedes A-Class (W169)	2004 - 2012	Mercedes B-Class (W245)	2005 - 2011
Mercedes C-Class (W203)	2004 - 2007	Mercedes E-Class (W211)	2002 - 2009
Mercedes R-Class (W251)	2006 - 2013	Mercedes CLK (C209)	2004 - 2009
Mercedes GL (X164)	2006 - 2010	Mercedes ML (W164)	2005 - 2011
Mercedes SLK (R171)	2008 - 2011	Mercedes SL55-AMG (R230)	2002 - 2008
Mercedes SL63-AMG (R230)	2008 - 2012	Porsche 911 (997)	2004 - 2008
Porsche Boxster (987)	2004 - 2008	Porsche Cayenne (1/2 Gen.)	2002 - 2016
Porsche Cayman (987)	2005 - 2009	Porsche Macan (1st Gen.)	2014 - 2016
Porsche Panamera (970)	2009 - 2016		

Note: this interface is for use with amplified vehicles only.

FEATURES

- Aids in the installation of a double DIN aftermarket stereo
- Allows the retention of the vehicles original audio over fibre optic network
- Can be used with any aftermarket harness

DISCLAIMER

The information provided in this document is subject to change without notice due to manufacturer changes and/or improvements to the product/s. This instruction manual is based on documented data and research. The manufacturer of this product cannot be held responsible for any changes made to the vehicle by the manufacturer or damages that may occur through the installation of this product in accordance with the steps outlined herein.

ABOUT PRODUCT

The CT51-MC07 is an amplifier retention adapter for select Mercedes and Porsche vehicles. By utilising the Mercedes/Porsche amp retention interface along with the universal harness, you are able to retain the vehicles audio when upgrading to an aftermarket radio.

Please note: this product is for use on vehicles that have fibre optic amplified systems.


CONTENTS

- Fibre Optic Retention Interface
- Universal Wiring Harness
- Instructions

PRIOR TO INSTALLATION

*Read the manual prior to installation. Technical knowledge is necessary for installation. The place of installation must be free of moisture and away from heat sources. Please ensure that the correct tools are used during the installation to avoid damage to the vehicle or product. **Connects2 can not be held responsible for the installation of this product.***

WIRING GUIDE



TECHNICAL SUPPORT

Connects2 want to provide a fast and suitable resolution should you encounter any technical issues. With this in mind, when contacting Connects2, try to provide as much Information as possible. This will speed up the process and help us to help you.

Please use our dedicated online technical support centre: support.connects2.com